
DAY 9 - Switch Interfaces Switch Interface



Viewing Interfaces:

From SW1:

• **Viewing** SW1's interface (Same command as router): show ip interface brief

SW1#show ip interface	brief				
Interface	IP-Address	OK?	Method	Status	Protocol
FastEthernet0/1	unassigned	YES	manual	down	down
FastEthernet0/2	unassigned	YES	manual	up	up
FastEthernet0/3	unassigned	YES	manual	up	up
FastEthernet0/4	unassigned	YES	manual	up	up
FastEthernet0/5	unassigned	YES	manual	down	down
FastEthernet0/6	unassigned	YES	manual	down	down
FastEthernet0/7	unassigned	YES	manual	down	down
FastEthernet0/8	unassigned	YES	manual	down	down
FastEthernet0/9	unassigned	YES	manual	down	down
FastEthernet0/10	unassigned	YES	manual	down	down

None of the interfaces have no IP Assignment because a Switch is a Layer
 2 Device while IP Address is a Layer 3 Addressing.

 There are reasons to assign IP Addresses to Switch's interfaces, but that comes later.

Router vs. Switch Interfaces:

- Router interfaces have the shutdown command applied by default (administratively down/down State)
- Switch interfaces DO NOT have the shutdown command applied by default.
 - Will be in the up/up state if connected to another device.
 - Will be in the down/down state if NOT connected to another device.
- View Speed and Duplex of each interface via show interfaces status

SW1#show	interfaces status					
Port	Name	Status	Vlan	Duplex	Speed	Type
Fa0/1		notconnect	1	auto	auto	10/100BaseTX
Fa0/2		connected	1	auto	auto	10/100BaseTX
Fa0/3		connected	1	auto	auto	10/100BaseTX
Fa0/4		connected	1	auto	auto	10/100BaseTX
Fa0/5		notconnect	1	auto	auto	10/100BaseTX
Fa0/6		notconnect	1	auto	auto	10/100BaseTX
Fa0/7		notconnect	1	auto	auto	10/100BaseTX
Fa0/8		notconnect	1	auto	auto	10/100BaseTX
Fa0/9		notconnect	1	auto	auto	10/100BaseTX
Fa0/10		notconnect	1	auto	auto	10/100BaseTX
Fa0/11		notconnect	1	auto	auto	10/100BaseTX
Fa0/12		notconnect	1	auto	auto	10/100BaseTX
Fa0/13		notconnect	1	auto	auto	10/100BaseTX

- Name: Description of an interface.
- Status: Connected or Not Connected
- VLAN: Will be covered later.
- Duplex: Direction of sending/receiving data.
- Speed: Depend on the Speed of the slower of the two (The interface vs. The device connecting to that interface).
 - eg: 10 Mbps device connecting to the 100 Mbps port will make the communication speed of this connection = 10 Mbps.
- Type: 10 (Ethernet, Slower than Fa) and 100 (Fast Ethernet or Fa)
 - No 1000 or 10G since these are Fa (Fast Ethernet) interfaces an not G (Gigabit Ethernet)

Duplex:

```
Switch(config) #interface f0/1
Switch(config-if) #duplex ?
auto Enable AUTO duplex configuration
full Force full duplex operation
half Force half-duplex operation
```

• Full Duplex:

 The device can send and receive data AT THE SAME TIME, it does not have to wait. (Most Modern Devices have this capabilities.)


Half Duplex:

- The device cannot send and receive data at the same time.
- If it is receiving a frame, it must wait before sending a frame.
- eg: Hub

Hub:




- Is considered to be a Layer 1 Device instead of Layer 2 because it performs similar function to switches (Frame Routing) but without the use of any MAC Addressing or MAC Table.
- More similar to a networking repeater.
- Will **Always Flood** the frames regardless of the frame's type.
- Devices connected to a Hub must always operate in **Half-Duplex** mode.
- Have a mechanism to deal with collisions called CSMA/CD.



1 Collision Domain


CSMA/CD in



<u>C</u>arrier <u>Sense Multiple Access with <u>Collision Detection</u>
</u>

- Used in Half-Duplex situation (like Hub network) to deal with collisions.
- Before sending frames, devices LISTEN to the Collision Domain until they
 detect that other devices are not sending.
- If a **Collision** does occur, the device sends a jamming signal to inform the other devices that a collision happened.
- Each device will wait a random period of time before sending frames again.

Collision Domain in Switches




- As established, Switches are considered a Layer 2 Device due to usage of MAC Addressing, Frame Forwarding etc.
- Collisions rarely occur (More of a configuration fault rather than normal usual occurrences like in Hub)
- Devices connected to a Switch can operate in Full-Duplex mode.


Speed:

```
Switch(config-if)#speed ?

10 Force 10 Mbps operation
100 Force 100 Mbps operation
auto Enable AUTO speed configuration
```

- Interfaces that can run at different speeds (10/100 or 10/100/1000 have default settings of speed auto and duplex auto
- Interfaces advertise their capabilities to the neighboring device, and they
 negotiate the best speed and duplex settings they are capable of.






What if auto-negotiation is disabled on the device connected to the Switch?

- **Speed**: The switch will try to sense the speed that the device is operating at.
 - If it fails to sense the speed, it will use the slowest supported speed
 - eg. 10 Mbps on a 10/100/1000 Interface

• Duplex:

If the speed is **10 or 100** Mbps, the switch will use **Half-Duplex**. If the speed is **1000** Mbps or greater, the switch will use **Full-Duplex**.



Interfaces Error

```
show interfaces {interface-name} (Like routers).
  Switch#show interfaces f0/1
  FastEthernet0/1 is down, line protocol is down (disabled)
    Hardware is Lance, address is 0001.c7d2.8a01 (bia 0001.c7d2.8a01)
   BW 100000 Kbit, DLY 1000 usec,
       reliability 255/255, txload 1/255, rxload 1/255
    Encapsulation ARPA, loopback not set
    Keepalive set (10 sec)
    Half-duplex, 100Mb/s
    input flow-control is off, output flow-control is off
    ARP type: ARPA, ARP Timeout 04:00:00
    Last input 00:00:08, output 00:00:05, output hang never
    Last clearing of "show interface" counters never
    Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
    Queueing strategy: fifo
    Output queue :0/40 (size/max)
    5 minute input rate 0 bits/sec, 0 packets/sec
    5 minute output rate 0 bits/sec, 0 packets/sec
       956 packets input, 193351 bytes, 0 no buffer
       Received 956 broadcasts, 0 runts, 0 giants, 0 throttles
       0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
       0 watchdog, 0 multicast, 0 pause input
       0 input packets with dribble condition detected
       2357 packets output, 263570 bytes, 0 underruns
       0 output errors, 0 collisions, 10 interface resets
       0 babbles, 0 late collision, 0 deferred
       0 lost carrier, 0 no carrier
       0 output buffer failures, 0 output buffers swapped out
```

Interesting statistics (Routers have similar statistics):

```
956 packets input, 193351 bytes, 0 no buffer
Received 956 broadcasts, 0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 watchdog, 0 multicast, 0 pause input
0 input packets with dribble condition detected
2357 packets output, 263570 bytes, 0 underruns
0 output errors, 0 collisions, 10 interface resets
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier
0 output buffer failures, 0 output buffers swapped out
```

Runts: Frames that are Smaller than the minimum Frame size (64 Bytes)

Giants: Frames that are Larger than the maximum Frame size (1518 Bytes)

CRC: Frames that failed the CRC Check (Ethernet FCS trailer)

Frame: Frames that have an incorrect format (due to errors)

Input Errors: Total of various counters, including the above four.

Output Errors: Frames the switch tried to send but failed due to errors.

Summary

SW1#show	interfaces	status					
Port	Name		Status	Vlan	Duplex	Speed	Type
Fa0/1			notconnect	1	auto	auto	10/100BaseTX
Fa0/2			connected	1	auto	auto	10/100BaseTX
Fa0/3			connected	1	auto	auto	10/100BaseTX
Fa0/4			connected	1	auto	auto	10/100BaseTX
Fa0/5			notconnect	1	auto	auto	10/100BaseTX
Fa0/6			notconnect	1	auto	auto	10/100BaseTX
Fa0/7			notconnect	1	auto	auto	10/100BaseTX
Fa0/8			notconnect	1	auto	auto	10/100BaseTX
Fa0/9			notconnect	1	auto	auto	10/100BaseTX
Fa0/10			notconnect	1	auto	auto	10/100BaseTX
Fa0/11			notconnect	1	auto	auto	10/100BaseTX
Fa0/12			notconnect	1	auto	auto	10/100BaseTX
Fa0/13			notconnect	1	auto	auto	10/100BaseTX

- View switch's interfaces using show interfaces status
 - Each interface do not have shutdown applied by default (No administratively down like Routers).
 - Will be in up/up state if connected to another device.
 - Be in down/down state if not connected.
 - Duplex: Full, half, or auto
 - Speed: Depends on the slower speed of either the interface or the device connected to the interface.
 - Type: Slower speeds than the interface and up-to-and-including the speed of the interface. (100Mbps Interface includes both 10Mbps and 100Mbps but not 1000Mbps)

```
269 packets input, 71059 bytes, 0 no buffer
Received 6 broadcasts, 0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
7290 packets output, 429075 bytes, 0 underruns
0 output errors, 3 interface resets
0 output buffer failures, 0 output buffers swapped out
```

- View specific switch interface's detail using show interfaces {interfacename}
 - Runts: Smaller than 64 Bytes (Minimum)
 - Giants: Larger than 1518 Bytes (Maximum)
 - CRC: Failed CRC Check
 - Frame: Incorrect Format
 - Input Error: Total Counters
 - Output Error: Switch failed to send
- Duplex: Direction of data communication.
 - Full: Send and Receive at the same time (eg. SWITCH networks).


Half: Must wait before sending (eg. HUB networks)

HUB:

- Considered to be a Layer 1 device due to no MAC address nor table being used.
- Will always broadcast frames regardless of type.
- Collisions common.

CSMA/CD:

- Used in Half-Duplex situation.
- Carrier Sense Multiple Access with Collision Detection
- Devices listen to the collision domain.
- If a collision occur, the device sends a jamming signal to the collision domain.
- Each device waits a random period of time before resending frames again.



- Auto-Negotiation (speed and duplex):
 - Interfaces usually can run at different speeds (10/100 or 10/100/1000)
 have default settings of speed auto and duplex auto.

- Interfaces advertise their capabilities to connected device and negotiate the speed and duplex.
- If Auto-Negotiation is Disabled:
 - Speed:
 - Try sensing the speed the connected device is operating at. If failed, it uses the slowest supported speed. (10Mbps on a 10/100/1000 Interface)
 - Duplex:
 - Speed of 10 or 100Mbps, the switch uses Half-Duplex.
 - Speed of **1000Mbps** or higher, the switch uses **Full-Duplex**.